

Recommendations on Adding A/C to the GO



Two approaches can be taken to add A/C to the SylvanSport GO: using a free standing unit or incorporating a small window style unit. The free standing units are larger and consume more floor space. Small window units tend to be lower in cost but necessitate some modification to the tent to incorporate.

Requirements:

1. The A/C unit must draw a low amperage (6 – 7 amps max)
2. Use a high amp (15+ amps) extension cord for connecting power.
3. Make a port in the tent wall using scrap material and Velcro fasteners. The unit can hang below the bed platforms to the side of the trailer so the back of the unit exhausts to the outside.
4. When not in use, the unit can be removed and the port sealed.

