



GO - Spare Tire Mounting Bracket Assembly Installation Instructions

What you get:

Your Spare Tire Mounting Bracket Assembly comes with all the hardware you will need, attached and in its correct location - ready for installation.



What you need:


Before you begin, you will need to gather the following tools:



1. Portable drill with 1/4" metal drill bit
 2. Clamp
 3. Tape measure
 4. Socket wrench with 7/16" socket
 5. 7/16" wrench
 6. Two 13mm wrenches*
- *Note: Adjustable wrenches will also work for this.


Step 1

On the passenger side (left, as you are facing the front of the GO), place the Spare Tire Bracket Assembly 16" from the inside of the vertical pillar, with bracket hook attached under cross bar, as shown.



Step 2

Using the 7/16" wrench, loosen the nuts on the back of the bracket, so the deck mounting plate is loose enough to raise up and down.



Step 3

Locate the Spare Tire Bracket Assembly to the GO deck, as shown and clamp securely. Be sure assembly is vertical and not angled.



Step 4

From the underside of the GO, slide the two T-nuts into the T-slot in the GO frame and slide to the left, until they are in alignment with the mounting holes on the bracket.



Customer Service:
info@sylvansport.com 828.393.4927



GO - Spare Tire Mounting Bracket Assembly Installation Instructions

Step 5

Align the supplied bolts (M8 x 20mm) and washers in the holes and into the T-Nuts, as shown, then tighten securely.



Step 8

From underneath the GO, slide washer and nut onto bolt and secure tightly with the 13mm wrench.



Step 6

Using the existing hole in the adjustable bracket as your guide, drill a hole through the diamond-plate deck and the top aluminum flange of the frame, using the 1/4" metal drill bit.



Using the 13mm wrenches (or adjustable), tighten both the top bolt (M8 x 30mm) and the lower nut, until the bracket is secure to the deck.



Step 7

Push the bolt (M8 x 30mm) and washer through the adjustable bracket hole as well as the hole in the deck that you drilled.



Step 9

Finally, using the 7/16" socket and 7/16" wrench, tighten the adjustable bracket securely.



Final Step

Using a lug wrench, mount your wheel/tire to the bracket, check to make sure everything is securely tightened. Do an occasional safety check to insure everything is secured properly for travel.